



ETATRON D.S. In line electrode holder

Portasonda tubolare per tubazione

Assembly instruction - Istruzioni di assemblaggio (Etatron code 2143001)

ENGLISH

- 1) Assemble the O ring 2075 onto the coupling.
- 2) Insert the electrode into the protection and the washer.
- 3) Fit the gasket snugly onto the electrode, then push the whole thing into the coupling seat.
- 4) Screw the coupling into the system pipeline first, and then screw in the protection. Make sure that the different pieces are screwed tight and check that everything fits well.
- 5) For normal maintenance or to replace the electrode, dismantle the holder by carrying out the assembling steps in the reverse order. I.E. : unscrew the tube nut, take out the cable gasket from its seat, unscrew the protection, pull out the electrode.

ITALIANO

- 1) Montare l'OR. 2075 sul manicotto.
- 2) Inserire l'elettrodo nella protezione e quindi nella rondella.
- 3) Montare la guarnizione sull'elettrodo facendola aderire in modo uniforme, quindi spingere il tutto nella sede del manicotto.
- 4) Avvitare il manicotto sul tubo dell'impianto, quindi avvitare la protezione; prestare particolare cura nell'eseguire queste operazioni, stringendo a fondo i vari pezzi nell'avvitarli.
- 5) Se all'occorrenza, si dovesse sostituire l'elettrodo seguire le fasi di smontaggio invertendo l'ordine di quelle di montaggio.

